# u purple.

Naomi 5G MiFi Quick Guide



(##) Direct Link: https://download.upurple.com.tw/




Scan for download the Naomi app and Quick Guide

# Contents 目錄

■ Package contents 內容物	p.2
② Hardware Installation 硬體安裝	p.3
❸ Booting & Internet Connection 啟動產品&連結網路	p. 4
❹ SSID Connection & Login 連接SSID並登入	p. 5
⑤ Charge Naomi 充電Naomi	p. 6
Safety Regulations 安全規範	p.7

## ● Package contents 內容物


1.
5G MiFi
υ ρυτρle.



3. Naomi


4.

- 1.Naomi 5G MiFi
- 2.USB Type-C傳輸線
- 3.快速使用手冊
- 4.電池



<sup>\*</sup>注意: 若更換非 Naomi 之電池,可能存在電池爆炸之風險。


## ❸ Booting & Internet Connection 啟動產品&連結網路



Stepl: 長按電源鍵3秒便會開啟裝置。

Step2: 查看LED燈確認是否有成功連上行動網路 (5G亮綠燈、4G亮橘燈、無網路紅燈綠燈閃爍)

## 4 SSID Connection & Login 連接SSID並登入




Q: 如何連上Naomi?

Step1: 把Naomi翻到背面把後蓋打開,推開鎖扣將電池取出,即可看到資訊貼紙。

Step2:找到對應的網路名稱SSID,並登入Naomi。

## 6 Charge Naomi 充電Naomi



Q: 如何充電?

A:使用附贈的USBType-C線連結電源變壓器或電腦的USB充電輸出口即可充電。

## ◎ Safety Regulations 安全規範

#### \* 台灣無線設備的警告聲明:

「取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。

前述合法通信,指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。」

\*減少電磁波影響,請妥適使用。

電波功率密度MPE標準值為: 0.35mW/cm², 送測產品實測值為: 0.05114mW/cm², 建議使用時設備天線至少距離人體20cm。

#### LTE 頻段宣告:

5G MiFi Router支援LTE FDD 700/1800/2600MHz

#### NR 頻段宣告:


5G MiFi Router支援NR FR1 TDD 3500MHz

## Contents


Package contents	p.9
2 Hardware Installation	p.10
3 Booting & Internet Connection	p.11
4 SSID Connection & Login	p.12
5 Charge Naomi	p.13
Safety Regulations	p.14

## Package contents

J. 5G MiFi U purple.




3. Naomi




- 1. Naomi-5G MiFi
- 2. USB Type-C cable
- 3. Battery
- 4. Quick guide

### 2 Hardware Installation




<sup>\*</sup> Caution: Risk of explosion if battery replacement is not from U purple.

## 3 Booting & Internet Connection



Step 1: Press the power key for 3 seconds to turn on the device. Step 2: Check the LED lighting if the device has successfully connected to the mobile network. (5G was green light > 4G was orange light > No network red and green flashing.)

## 4 SSID Connection & Login




Q: How to connect to the Naomi?

Step 1: Push up the lid removing slot to open back lid. Unlock the lock and take the battery out of a Naomi, you can see the information sticker.

Step 2: Find this name(SSID) and enter password to connect wireless to Naomi.

## 6 Charge Naomi



Q: How to charge Naomi?

A: Use the in-box power adapter or computer's USB port to charge Naomi with the included USB Type-C cable.

## Safety Regulations

\* Taiwan radio equipment warning statement:

Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristic andfunctions of the original design of the certified lower power frequency electric machinery. The application of lower power frequency electricmachineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists.

\* To reduce the influence of electromagnetic waves.

Please use it correctly. Electromagnetic wave power density MPE standard value: 0.

35mW/cm². Measured value of products submitted for inspection: 0.05114mW/cm².

It is recommended to use the antenna at least 20cm away from the human.

\* LTE band announcement: 5G MiFi router supports LTE FDD 700 / 1800 / 2600MHz.

\* NR band announcement: 5G MiFi Router supports NR FR1 TDD3500MHz.

